


## 5 Exploded View and Parts List

-You can search for updated part codes through ITSELF web site.

URL : <http://itself.sec.samsung.co.kr>

### 5-1 Exploded View



## 5-2 LS20MEHSFV/XBM Parts List

| Location.No | CODE-NO     | SPECIFICATION & DESCRIPTION              | Q'TY | SA/SNA | REMARK |
|-------------|-------------|--|------|--------|--------|
| T0003       | BN96-04539A | ASSY COVER P-FRONT;LS20MEW,,ABS HB,,BK26 | 1    | S.A    |        |
| M0112       | BN63-02911A | COVER-FRONT;LS20MEW,ABS,HB,BK26,HIGHGLOS | 1    | S.N.A  |        |
| T0056       | BN63-02912A | COVER-DECORATION;LS20MEW,ABS,HB,GR70(SVM | 1    | S.N.A  |        |
| M0130       | BN67-00168A | LENS LED;LS17ME/LS19ME,PC CLEAR,TP-15    | 1    | S.N.A  |        |
| T0023       | BN64-00473A | KNOB POWER;LS17ME/LS19ME,ABS,NTR         | 1    | S.N.A  |        |
| M0007       | BN64-00474A | KNOB-FUNCTION;LS17ME/LS19ME,ABS+PC,BK07  | 1    | S.N.A  |        |
| M0215       | BN07-00374A | LCD-PANEL;CLAA201WA04,Doppler,6bit Hi-FR | 1    | S.A    |        |
| M0006       | BN96-04542H | ASSY SHIELD P-COVER;LS20MEW,SECC,T1.0,CP | 1    | S.A    |        |
| M0174       | BN44-00182A | IP BOARD;T034,206BW,3.3 ~4.4mA,7.0 ~8.0m | 1    | S.A    |        |
| M0014       | BN94-01387H | ASSY PCB MAIN-PTZ,W/W;LS20MEHSFV*        | 1    | S.N.A  |        |
| M0013       | BN96-04540E | ASSY COVER P-REAR;LS20MEW,,HIPS HB,,BK07 | 1    | S.A    |        |
| M0006       | BN63-02910A | COVER-REAR;LS20MEW,HIPS,HB,BK07          | 1    | S.N.A  |        |
| M0113       | BN61-02806A | BRACKET-VESA;LS20MEW,SECC,T1.0           | 2    | S.N.A  |        |
| M0006       | BN63-02909A | COVER-REAR SUB;LS20MEW,HIPS,HB,BK07      | 1    | S.A    |        |
| M0003       | BN96-01953E | ASSY STAND P;-;LS19MDB,-,HIPS,BK07,-     | 1    | S.A    |        |